

# CONCRETE MOUNTING INSTRUCTIONS by FLEXPOST®

## Tools Required:

- Marker
- High Speed Power Drill
- 1/2" Masonry Drill Bit
- Socket Wrench with 3/4" Drive

## Parts Included:

- 1 - Base Plate & Torsion Spring
- 4 - Concrete Wedge Bolts

1



- Position base plate and spring in desired mounting location.

2



- Mark the four base holes to be drilled.

3



- Use high speed power drill with 1/2" masonry bit and core drill each hole 5" in depth.

4



- Position base plate and spring over holes .

5



- Using socket wrench with 3/4" drive, thread all four concrete wedge bolts into core drilled holes.

6



- Tighten concrete wedge bolts until head securely holds base plate to surface.

**FLEXPOST** 

4190 Sunnyside Drive  
Holland, MI 49424 USA  
Phone (866) 577-2588 or (616) 928-0829  
Fax (616) 928-1138